



**711395, In-Car Mounting Bracket for SAAB 95 - 2010>**



- Unclip the gear shift surrounds
- Remove the two Torx bolts in the recess securing the front fascia panel
- Unclip and remove the black fascia panel
- Unclip the chrome surround/insert
- Locate the bracket with the screw in the left of the recess to the lower left of the media screen
- Refit all parts

[www.co-star.co.uk](http://www.co-star.co.uk)

t: +44 (0) 1423 340066

e: [sales@co-star.co.uk](mailto:sales@co-star.co.uk)

**Co-star will not be liable for any damage caused when fitting the bracket**