

CO:STAR*

711277, In-Car Mounting Bracket for Volvo V40 - 2013>



- Unclip and remove the central air vent assembly. Disconnect the wiring feeds and set aside
- Remove the two Torx 15 bolts in the corners and pull the trim out some 15mm
- Slide the bracket behind this panel aligning it with the contour of the outer wall
- Refit all parts

www.co-star.co.uk

t: +44 (0) 1423 340066

e: sales@co-star.co.uk

Co-star will not be liable for any damage caused when fitting the bracket