

**CO:STAR\***

711437, In-Car Mounting Bracket for Transit Jumbo 2014



- Unclip the heater control fascia
- Remove the torx screw in the upper left corner securing the matrix unit. Loosen the other Torx to enable the unit to be levered forward some 3/4mm
- Locate the bracket behind the unit with the upper left torx
- Refit the trim

[www.co-star.co.uk](http://www.co-star.co.uk)

t: +44 (0) 1423 340066

e: [sales@co-star.co.uk](mailto:sales@co-star.co.uk)

**Co-star will not be liable for any damage caused when fitting the bracket**